Heat and Control, Inc.
Packaging Service Department
Technical Publication 041410
CCW-R; Atlas; ITPS; TSC

## RCU Touch Screen Replacement Procedure



Date: 04.14.10

## **Packaging Service Department:**

Heat and Control, Inc. 187 West Airport Rd Lititz, PA 17543 USA

Phone: 800.648.5313 Fax: 717.519.5260

www.heatandcontrol.com

## **Corporate Headquarters:**

Heat and Control, Inc. 21121 Cabot Blvd Hayward, CA 94545 USA Phone: 800.227.5980

Fax: 510.259.0600

www.heatandcontrol.com







photo 1: Required Tools



photo 3: Replacement RCU Front Border



photo 5: Touch Screen



photo 2: Replacement Touch Screen Package



photo 4: Touch Screen Adhesive Strip




photo 6: Replacement Camera Cover







photo 7: Remove the 8 Phillips head screws from the back of the RCU.




photo 9: Disconnect all cable mounting straps.



photo 11: Disconnect the touch screen communication cable carefully.




photo 8: Open the front of the RCU.





photo 10: Remove cables from electrical boards.



 $_{\mbox{\scriptsize photo 12:}}$  Disconnect the fan cable from the back of the RCU board.





photo 13: Disconnect the Backlight Power Supply connector.



photo 15: Support the touch screen to remove the grounding cable and mounting straps.




photo 17: Disconnect the mounting straps while securely holding the touch screen.




photo 14: Disconnect the cables to the RCU bd.




photo 16: Remove the ground cable.



photo 18: After disconnecting cables, locate the screws to separate the touch screen mounting plate from the RCU.





photo 19: Place the touch screen face down on a clean, flat surface to disconnect the ribbon.



photo 21: Carefully remove the metal plate and LCD screen and set it aside.




photo 23: Use a utility knife to carefully lift the front cover.



photo 20: Separate the back of the touch screen from the RCU front.



photo 22: Place the front of the RCU face up.



photo 24: Firmly and smoothly remove the old cover from the front.







photo 25: Begin the slow process of removing the glue that remains on the RCU front.



photo 27: Lift the camera cover with a utility knife.




photo 29: Gently press the touch screen from the front side and loosen the screen.



photo 26: It may take an hour of rubbing to remove the adhesive.



photo 28: Peel the camera cover back to remove.



photo 30: Lift out the old touch screen and set it aside.







photo 31: Peel the adhesive strip from the RCU cover inner slot.



photo 33: Remove the white protective layer from the blue border strip.




photo 35: Carefully place the oval covering the camera area into position.



photo 32: After all the adhesive is removed, begin the installation of the new parts.




photo 34: Separate the camera cover oval's three layers and remove the bottom layer.




photo 36: Remove the top white oval.






photo 37: Separate the bottom layer from the thin flexible yellow strip revealing the adhesive.




photo 39: Continue to gently lower the sides of the strip aligning the edges with the slot.




photo 41: Separate the top layer from the thin flexible yellow strip revealing the adhesive.




photo 38: Carefully insert the adhesive side into position on the RCU's inner slot as shown.




photo 40: Press and hold the strip while pulling the backing out of the RCU front.



photo 42: The new adhesive strip is shown with the top yellow layer removed.





photo 43: Remove the protective layer from the front side of the new touch screen.



photo 45: Place the touch screen into position and hold the ribbon side up.



photo 47: Lower the touch screen in place.




photo 44: Place the touch screen in the RCU with the ribbon number-side up by the ribbon slot..




photo 46: Tuck the ribbon through the slot.



photo 48: Remove the protective plastic sheet.





photo 49: Separate the white backing and bend it in half without creasing.



photo 51: Check the blue cover's position and smooth it slowly as the backing is removed.



photo 53: Use a utility knife blade to lift the top corner of the protective plastic to remove it.



photo 50: Place the touch screen cover precisely and lower slowly to avoid creases or bubbles.



photo 52: Be very careful to align the cover since it must be placed correctly the first time.



photo 54: Clean the front with a soft cloth.






photo 55: Hold the cover using a clean cloth and examine the thin ribbon slot.



photo 57: Attach the RCU front to the mounting plate using the Phillips head screws.




photo 59: Hold the front of the RCU into position and carefully attach the mounting straps.



photo 56: Pass the ribbon through the slot.



photo 58: Attach cables and install clamps.



photo 60: Tighten the 8 screws to close the RCU.



